


# Proflex

ROOM SIGNAGE



v05

## Proflex ProDVX Touch Panel

### Setup Guide

**PRO DVX**

# CONTENTS

Preparations	<b>3</b>
Room Signage Browser Installation	<b>3</b>
Room Signage touch panel activation	<b>4</b>
Room Signage Settings	<b>5</b>
Exchange Connection Settings	<b>5</b>
Proflex screen settings	<b>6</b>



## Preparations

Switch the ProDVX screen on and configure the Internet or WiFi connection

- Verify that you are connected to the Internet with the browser

Have a USB memory stick ready with the roomsignage-xxx.apk installation file

If this is an update first remove the current Room Signage Browser


1. On the ProDVX screen select Settings. 
2. In the ProDVX Settings select **Apps**.
3. Select the current Room Signage Browser App  and select **Uninstall**.

## Room Signage Browser Installation

On the ProDVX main touch panel click on the Apps icon.

Plug the USB stick into the ProDVX touch panel.

Open the “Es File Explorer” on the ProDVX touch panel.

In the “Es File Explorer”, navigate on the left to **Local/usb\_storage** and click on the roomsignage-xxx.apk file. 


Select **Install**.

After the App is installed, remove the USB stick.


Start the Room **Signage Browser App**  and follow the configuration instructions.

# Room Signage touch panel activation

Have your Room Signage Activation code ready.




- Enter the code and click on "Activate".



- Click on "Continue".


# Room Signage Settings

You have to log in to enter or modify the settings. The default password is “proflex”.



- Enter the password and click on “Log in” to enter/modify the Profile Exchange connections settings.


## Exchange Connection Settings



If you have done this before you will see the previously entered settings on screen. If this is the first time you will have to enter the settings.

- If you are planning to use Exchange, select Yes.
- Enter your Exchange web service URL (EWS):  
For Exchange Online this is always <https://outlook.office365.com/EWS/Exchange.asmx>
- Enter your Proflex Exchange account name/email.  
You have created the earlier according to the Proflex Exchange Settings Guide.  
If you do not have these setting, please contact your system administrator.


- Enter your Proflex exchange account password.
- Click on “Validate”.




- Click on “Next” to enter/modify the Proflex screen settings.

## Proflex screen settings

Have your Room Signage Password and Room Resource Email Address ready.



- Select the language you want to use on the screen.
- Enter the Room Resource email address that is associated with this screen.
- Enter the Room name you want to display on the top left of the screen.
- Click on “Save” to store the entered or modified screen settings.



After saving you should see the entered name appearing on the top left of the screen.

- Click on “Close” to complete the configuration and return to the main screen.

